



## **Billericay Farm Services Auto Streamer Information Sheet**

*Setting the Auto Streamer flow rate on your controller (certain controllers only):*

*At 2 bar pressure, flow rate Approx 4.20 Ltr per minute.*

*At 3 bar pressure, flow rate Approx 6.25 Ltr per minute*

*Conduct a Jug test (preferably 15 seconds with a bucket then pour contents in to a two litre cylinder) to check your flow rates on each Auto Streamer. Take results and adjust controller accordingly to get desired flow rate.*

- Auto Streamers are not suitable for pressure based systems without additional devices
- The flow rates on used Auto Streamers will vary from that of new Auto Streamers bought as spares.
- New spare Auto Streamers will need a 'running in period' to match the output of older examples on the boom.
- Alternatively transfer the valves from your old Auto Streamers to the new spare bodies and the flow rate will be similar.
- Auto Streamers are not recommended for use at flow rates below 120ltrs per hectare.
- Auto Streamers are not height sensitive.
- Do not use Auto Streamers above 2.6 bar pressure.